


REPLACEMENT PARTS LIST FBK-H HI-SPEED DC TRIP UNIT WITH UNIVERSAL INPUT CONTROL VOLTAGE



REPLACEMENT PARTS LIST FBK HI-SPEED DC TRIP UNIT



<u>Part Number & Description</u>	<u>Part Number & Description</u>
A CA-8-14P-B-U (14 Pin Version) CA-8-19P-B-U (19 Pin Version) Control cable harness & connectors	K PCB-ST-20.2- <u>X</u> Auxiliary circuit board “ <u>X</u> ” varies with Hi-Speed trip unit part #
B PCB-ST-30.0 Transducer feed-through circuit board	L B-208 Micro-Controller based Trip unit
C CA-8-LAMBDA 24V Power supply input harness & connectors	M CA-8-KEY Key push button, harness & connector
D RL-100 Ground resistor	N T-815 Fuse Holder
E T-896 Triggered spark gap	P CA-8-TU-BL “Blue” harness & connectors
F PCB-ST-30.0 Spark gap circuit board	Q CA-1-24-HIGH-SPEED Internal transducer cable
G T-810-ZWS50-24 24V Power supply	R T-808 Capacitor
H T-810-4C24-P125 or T-810-2C24-P60 Hi-Voltage power supply Replacement part # depends on Hi-Speed part #	S CA-8-3P Impulse coil connector & harness
I CA-8-CTRL 24V Power supply control harness & connectors	T CA-1-24-FBK External DC transducer cable
J CA-8-TU-WT “White” harness and connectors	U B-355- <u>X</u> KA FBK transducer, factory calibrated Replace “ <u>X</u> ” with the following: “2.5” for 2500 Amp calibration “4” for 4000 Amp calibration “6” for 6000 Amp calibration

Call for replacement part pricing.

When ordering replacement parts, please provide serial number and complete part number of the Hi-Speed trip unit.